WIRING INSTRUCTIONS MODEL 983 & 503 FIREPLACE INSERTS

- 1. Connect the black wire of the power cord to the center pole of the toggle switch.
- 2. Connect one of the wires from the snap disc to the bottom pole of the toggle switch.
- 3. Connect the other wire from the snap disc, a wire from the top pole of the toggle switch, and one wire from each blower all together with wire nut. There should be four wires at this connection.
- 4. Connect white wire on power cord to the remaining wire from each blower. There should be three wires at this connection.
- 5. Connect the green wire to the mounting bolt of the motor with nut provided.

